

**TECHNICAL
INFORMATION**



Insulcon 1 Coat—Brick



PRODUCT

Insulcon 1 Coat—Brick is a 18kg bag factory blended, acrylic hi build render.

Note—**Insulcon 1 Coat—Brick** is not recommended for use on any other substrate except for brick/blockwork/concrete substrate..

SURFACE & PRODUCT PREPARATION

It is imperative that the substrate Insulcon 1 Coat—Brick is to be applied to is totally clean and free from dirt, dust, oils etc. Failure to do so can cause delamination resulting in damage to the finish product. Insulcon takes no responsibility for problems arising from this. In a clean bucket add approx 4-5 litres of clean . Then whilst mixing with a mechanical mixer, add contents of Insulcon 1 Coat—Brick bag into the bucket. A smooth paste mix is the desired finish to achieve maximum results, both in finish and application. If the mixture is too wet, it can be very messy and difficult to apply, resulting in hanging too long on the wall, making floating very hard and time consuming. If the mixture is too dry then it will be very difficult to apply as it will not glide on the wall and will tear when floating. This can also have an effect on drying time, resulting in a compromised fast cured product.

COVERAGE

When Insulcon 1 Coat—Brick is applied according to manufacturers instructions, Insulcon 1 Coat—Brick will cover approx 3 – 4 square metres.

Ideal application thickness of 5mm is recommended but this can vary depending substrate quality. (Thickness will obviously differ the coverage estimation)



Insulcon Pty Ltd
34 Swift Way
Dandenong South
VIC, 3175

Ph : 9768 2335
Fax: 9768 2337
E-mail: sales@insulcon.com.au
Web : www.insulcon.com.au

**TECHNICAL
INFORMATION**



Insulcon 1 Coat—Brick



Insulcon Pty Ltd
34 Swift Way
Dandenong South
VIC, 3175

Ph : 9768 2335
Fax: 9768 2337
E-mail: sales@insulcon.com.au
Web : www.insulcon.com.au

APPLICATION

Insulcon 1 Coat—Brick is to be applied using a steel trowel with even coverage over the desired substrate. Being a hibuild 1 coat render, means it is suitable for application to no more than 10mm per coat. If you need more build up than 10mm then this needs to be done in separate coats. Rainbow Render can be applied as a 2nd coat if the applicator is requiring a smoother base coat for texture application.

Insulcon recommends the Insulcon 1 Coat—Brick cure for 2-3 days before the application of any Rainbow Texture Coating.

Insulcon 1 Coat—Brick should only be applied in suitable weather. Rain, low temperatures, excessive warmth and windy conditions are not suitable conditions for Insulcon 1 Coat—Brick application. Insulcon 1 Coat—Brick can be assisted in its curing, by putting some moisture back into the wall when the product has dried. Meaning, spray the wall with a slight mist as this will enhance the curing of the materials leaving a superior finish.

SAFETY

- If swallowed: Rinse mouth and lips with water. Seek medical advice if discomfort occurs.
- If in Eyes: Flush eyes thoroughly with flowing water for 15 minutes.
Seek medical attention symptoms persist.
- If on skin: Wash thoroughly with soap and water.
- If Inhaled: Remove subject to fresh air. If symptoms persist seek medical attention.